

ASSEMBLY OF THE OUTDOOR BOX MEDIO / MAXI

- Place the box in the wall to set up the 8 holes:
 - 4 holes on in the upper and lower corners of the box
 - 4 central holes according to the model of central to be installed to fix the support
- After having drilled the holes fix the box with the supplied dowels.
- Apply the two pieces of noise absorbing adhesive to the bottom of the box.

